





Position	Référence pièce	Description	Echar	QTE	N/O	Option 1	Option 2	COMMENTAIRE
001	458406-0	LOCK LEVER L		1				
002	183J51-9	HANDLE SET		1				
C10	263005-3	RUBBER PIN 6		2		65	P2	
D10		INC. 14						
003	140A04-7	SUB CONTROLLER COMPLETE		1				
C10	806G56-1	INDICATION LABEL		1				
C20	817C42-3	SWITCH LABEL		1				
004	458570-7	SLIDER		1				
005	458405-2	LOCK ARM		1				
006	234204-4	COMPRESSION SPRING 8		1		65	P2	
007	650781-2	SWITCH C3JW-6B-P		1			P99	
008	458403-6	LOCK OFF LEVER		1				
009	458404-4	SWITCH LEVER R		1				
010	232454-5	TORSION SPRING 10		1				
011	620818-9	CONTROLLER		1				
012	644809-6	TERMINAL		1				
013	855G51-8	DUH602 SERIAL NO. LABEL		1				
014	183J51-9	HANDLE SET		1				
C10	263005-3	RUBBER PIN 6		2		65	P2	
D10		INC. 2						
015	266326-2	TAPPING SCREW 4X18		6		65	P2	
016	458407-8	LOCK LEVER R		1				
017	266326-2	TAPPING SCREW 4X18		1		65	P2	
018	855G45-3	DUH602 NAME PLATE		1				
019	183K21-4	HOUSING SET		1				
C10	252143-6	COLLARED HEX.NUT M5-8		2				
C20	424344-8	DAMPER		4		0	P1	
D10		INC. 22						
020	651083-9	SWITCH C3XA-1PSPM		1				
021	266326-2	TAPPING SCREW 4X18		4		65	P2	
022	183K21-4	HOUSING SET		1				
C10	252143-6	COLLARED HEX.NUT M5-8		2				
C20	424344-8	DAMPER		4		0	P1	
D10		INC. 19						
023	266326-2	TAPPING SCREW 4X18		2		65	P2	
024	265182-7	+ PAN HEAD SCREW M5X25		2		0	P1	
025	458399-1	PROTECTOR		1				
026	458400-2	FRONT GRIP E		1				
027	251476-6	H.S.H.BOLT M5X35 WITH WR		1			P1	
028	253416-0	DISH WASHER 5		1				
029	257678-2	SLEEVE 6		1				
030	422260-8	RUBBER SLEEVE 8		2				
031	233222-9	COMPRESSION SPRING 5		2				
032	458402-8	SWITCH LEVER F		1				
033	422261-6	RUBBER SLEEVE		1				
034	183J52-7	MOTOR HOUSING SET		1				
D10		INC. 40						
035	266490-9	TAPPING SCREW PT 2X6		3			P1	

Position	Référence pièce	Description	Echar	QTE	N/O	Option 1	Option 2	COMMENTAIRE
036	629352-6	STATOR		1				
037	652069-6	FLAT HEAD SCREW M3X6		3			P1	
038	266326-2	TAPPING SCREW 4X18		4	65		P2	
039	265178-8	PAN HEAD SCREW M4X16		4			P1	
040	183J52-7	MOTOR HOUSING SET		1				
D10		INC. 34						
041	211157-4	BALL BEARING 695ZZ		1			P2	
042	519557-5	ROTOR ASSY		1				
D10		INC. 41,43						
043	211032-4	BALL BEARING 608ZZ		1	2		P9	
044	422259-3	RUBBER SLEEVE 8		2				
045	140F22-5	GEAR HOUSING COMPLETE		1				
C10	424344-8	DAMPER		1	0		P1	
046	458417-5	GASKET		1				
047	211032-4	BALL BEARING 608ZZ		1	2		P9	
048	347361-0	FRICTION PLATE		1				
049	347362-8	CONNECTING ROD		1				
050	915211-3	BINDING HEAD SCREW M5X12		3	0		P1	
051	458408-6	GUARD E		1				
052	199599-1	SHEAR BLADE ASSEMBLY 600S SET		1				
C10	345205-8	BRANCH CATCHER		1	0		P1	
C20	911208-0	PAN HEAD SCREW M5X10		1	0		P3	
C30	188369-3	OIL VESSEL SET		1	0		P3	
D10		INC. 64,65						
053	265182-7	+ PAN HEAD SCREW M5X25		2	0		P1	
054	140B79-2	GEAR COMPLETE		1				
055	347362-8	CONNECTING ROD		1				
056	347361-0	FRICTION PLATE		1				
057	211499-6	BALL BEARING 626ZZ		1			P1	
058	443159-4	SEAL		1	2		P8	
059	140B62-9	GEAR HOUSING COVER COMPLETE		1				
060	265338-2	H.S.BOTTON HEAD BOLT M6X8		1				
061	265A29-1	HEX. SOCKET HEAD BOLT M4X16WRN		2				
062	915211-3	BINDING HEAD SCREW M5X12		2	0		P1	
063	458628-2	SPACER 600		1				
064	257465-9	RING 5		2				
065	253804-1	FLAT WASHER 6		2	65		P2	
066	458907-8	UNDER COVER		1				
068	265698-2	HEX. SOCKET HEAD BOLT M4X25WRN		2				
069	265A29-1	HEX. SOCKET HEAD BOLT M4X16WRN		2				
A01	459121-9	BLADE COVER 600S		1				
A02	195246-2	SAFETY GOGGLE		1	1		A5	
A03B	***DC18SD	DC18SD BATTERY CHARGER		1				
D10		COMPO-PARTS						
A03C	***DC18RC	DC18RC FAST CHARGER		1			A42	
D10		COMPO-PARTS						
A04B	197600-6	BATTERY BL1830B SET		1				
A04C	197280-8	BATTERY BL1850B SET		1			A45	